

RCA Remote Programming

- 1- Manually Turn on TV.
- 2- Hold down TV Button. (The on/off light will go on.)
- 3- While holding the TV button press the on/off button. (Light will go off.)
- 4- Hold both buttons for 3 seconds. (Light will go back on.)
- 5- Release both buttons. (Light will remain on.)
- 6- Press the play button. Wait 5 seconds. if the TV turns off, the code is one of the 10 it went through. If it does not turn off, press the play button every 5 seconds until it turns off.
- 7- *** Each time the play button is pressed, 10 codes are sent to the remote.***
- 8- When the TV turns off, hit the Reverse key every 2 seconds. When it finds the correct code the TV will turn back on.
- 9- Press the stop button to save the correct code.

Test to see if it works!!!